









### TURNING PAGER ON

- Open the flip and press any key to turn your pager on. The pager emits a 4-second power-up alert, and the Status screen displays.








### TURNING PAGER OFF

- From the Main menu, press  or  to highlight *POWER OFF* and press .
- Highlight *YES* and press .




### READING MESSAGES

- To read a message, (while previewing) press  or  to highlight the desired message and press .
- Press  or  to scroll through the text of a message or press  to page through the message.










### COMPOSING AND SENDING A MESSAGE

- From the Send Message menu, press  or  to highlight *WRITE MESSAGE* and press .
- After you finish composing the message, press .
- To send, return to the Send Message menu, press  or  to highlight *SEND MESSAGE* and press .










## DELETING A MESSAGE

- From the Main menu, press  or  to highlight the inbox containing the messages you want to delete and press .









## SETTING THE DATE AND TIME

- From the Main menu, press  or  to highlight *PREFERENCES* and press .
- Press  to highlight *SET TIME & DATE* and press .
- Press  or  to change the hour, minutes, and date. Press  or  to move between fields.















## SETTING THE ALARM













- From the Main menu, press  or  to highlight *PREFERENCES* and press .
- Press  or  to move between fields and  or  to increase or decrease the value in each field.
- At any time, press  to save the changes and return to the Preferences menu. Or press  to exit without saving your changes.













## PRIVATE TIME

- From the Main menu, press  or  to highlight *PREFERENCES* and press .
- Press  or  to highlight *PRIVATE TIME* and press .
- Press  or  to activate Private Time mode.

 Power on  
 MailBox  
 News/Info InBox  
 Send Message  
 Info-On-Demand  
 Address Book  
 Personal Folder/Move  
message to folder  
 News/Info Folder  
 Preferences  
 Vital Signs  
 Power Off  
 Message has been read  
 Message reply  
 Reply in progress

 Delete Message/Inbox  
 Successful Reply/Send  
 Unsuccessful Reply/Send  
 Message contains custom  
reply choices  
 InBox  
 InBox - messages read  
 News/Info InBox  
 InBox alert selected  
 Out of Range  
 Low Battery  
 Audible Alert/Alarm  
 Vibrate Alert/Quiet Mode  
 Private Time  
 Signature

	MailBox Alert, News/Info Alert
	Alarm/Set Alarm
	Set Time & Date
	Alert Volume/Key Click, Reminder Alert
	Transmitter Off
	Next/higher value
	Preceding/lower value
	Previous item
	Next item
	Move InBox Up
	Move InBox Down
	Battery Gauge

	Message Memory
	About Screen
	Back/Escape
	Yes/On
	No/Off
	News AutoPreview
	Set InBox History
	Next Message
	CAPS (not locked)
	CAPS Lock on
	Alt (not locked)
	Alt Lock On

**Note:**

A flashing icon denotes unread messages or a function in process.